



APS Power Saver Timer will be Set to 840 hours.

Standby Light

Power On/Off Rocker Switch

AutoPurge SystemTM
with PowerSaverTM
South-Tek Systems

Exhaust Muffler

Solenoid Valve with
-CSA Certification
-UL Listed
-FM Approved

1" x 1" x 1/2" NPT Tee will be Plumbed to Existing FPS Piping at a High Point within the System

1/2" NPT F Ball Valve (Normally Open)

Up to (6) APS Assemblies can be Plumbed to the APS Power Saver Timer

1/4" OD Tubing (Connection by Others)

120V / 60Hz / 1Phase Power Supply

		APS with Power Saver Timer Installation Drawing						
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES		MATERIAL:		FINISH:		WEIGHT:		
		TOLERANCES:		DRAWN BY: PJS		CHECKED BY:		APPROVED BY:
PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF SOUTH-TEK. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF SOUTH-TEK IS PROHIBITED.		DATE: 11/1/2013		DATE:		DATE:		
		PROJECT NAME: Power Saver Timer				SIZE: B	SCALE: 1:3	SHEET: 1 of 1
		NUMBER: A02-QCF-PST-TI				REVISION: 0		